

# Preface

---

This manual is prepared for the maintenance service for EP737 Micro-portable XGA DLP Projector. Maintenance procedures described in this manual are intended to isolate faulty parts and replace them in the field. It also aims to serve as a guide in procuring replacement parts for this product.

This manual is copyrighted and all rights are reserved. This product may not, in whole or in part, be copied, photocopied, translated or reduced to any electronic or machine readable form without prior written consent except for copies retained by the purchaser for backup purpose.

This manual includes system overview, major system assembly, components' description, and the "Troubleshooting" making explanations on how to detect errors. It also includes a flow chart for checking or correcting faults.

No warranty or representation, either expressed or implied, is made with respect to this documentation, its quality, performance, merchantability or fitness for particular purpose.

No event that the vendor will be liable for direct, indirect, special, incidental or consequential damages arising out of the user or inability to use this product or documentation.

## ■ NOTICE :

The information found in this manual is subject to change without prior notice. Any subsequent changes made to the data herein will be incorporated in further edition.

Copyright 2002, October  
All Rights Reserved  
Manual Version 1.0  
Document # 863-G04-01A  
P/N : 36.86305.001

## Table of Contents (I)

---

<b>Introduction.....</b>	<b>1-1</b>
Product Highlights.....	1-2
Technical Specifications.....	1-3
<b>Fundamental Principle.....</b>	<b>2-1</b>
Function Block Diagram.....	2-2
Optics.....	2-6
<b>Mechanical Construction.....</b>	<b>3-1</b>
Package Overview.....	3-2
Exploded Overview.....	3-4
Recommendation Spare Parts List.....	3-26
<b>Procedure of Disassembly.....</b>	<b>4-1</b>
Disassemble Lamp Module.....	4-3
Disassemble Top Cover and Keypad Board.....	4-4
Disassemble Left Cover, Right Cover and I/O Bezel Module.....	4-6
Disassemble Front Cover.....	4-8
Disassemble Thermal Board and Main Board.....	4-10
Disassemble Ballast and Fan Module.....	4-12
Disassemble DC-DC Board and Interlock Switch.....	4-14
Disassemble Engine, DMD and DMD Board.....	4-15
Disassemble Color Wheel, Photo Sensor Board and Thermal Switch.....	4-17
Disassemble Elevator Module.....	4-18
<b>Function of Boards.....</b>	<b>5-1</b>
DMD Board.....	5-2
Main Board.....	5-7
Keypad Board.....	5-15
Thermal Board.....	5-16

## Table of Contents (II)

---

DC-DC Board.....	5-21
Ballast.....	5-23
<b>Specifications.....</b>	<b>6-1</b>
Lamp Specifications.....	6-2
DMD Specifications.....	6-5
DC-DC Specifications.....	6-8
Lamp Driver Specifications.....	6-9
<b>Troubleshooting.....</b>	<b>7-1</b>
Equipment Needed.....	7-2
Main Procedure.....	7-2
<b>Function Test &amp; Alignment Procedure.....</b>	<b>8-1</b>
Product.....	8-2
Test Equipment.....	8-2
Test Condition.....	8-2
Test Display Modes and Patterns.....	8-3
Inspection Procedure.....	8-9
<b>Firmware Upgrading Procedure.....</b>	<b>9-1</b>
Equipment Needed.....	9-2
Setup Procedure.....	9-3
Upgrading Procure.....	9-4
<b>DDC Key-In Procedure.....</b>	<b>10-1</b>
Equipment Needed.....	10-2
Setup Procure.....	10-3
DDC Key-in Procedure.....	10-4
<b>Appendix.....</b>	<b>11-1</b>
Serial Number System Definition.....	11-2

# Introduction



This manual is applied to 0.7"\*1 DMD Color Projector with digital imaging functionality based on Digital Micromirror Device (DMD) technology. It's the mode of single panel, 150 watt long life P-VIP lamp. The manual gives you a brief description of basic technical information to help in service and maintaining the product.

Your customers will appreciate the quick response time when you immediately identify problems that occur with our products. We expect your customers will appreciate the service that you offer them.

This manual is for technicians and people who have an electronic background. Send the product back to the distributor for repairing and do not attempt to do anything that is complex or is not mentioned in the troubleshooting.

## 1-1 Product Highlights

- One panel 0.7" DMD XGA projection system with 1300 ANSI lumens (Marketing)
- OSRAM 150 - Watt Compact P-VIP Lamp (user replaceable)
- High efficiency cooling system with low system acoustic noise level
- Light weight Approx. 3.9 lbs.
- Manual focus projection 1 : 1.2 zoom lens
- True 1024 x 768 resolution, 16.7M True colors
- With up, down, left, and right screen reverse
- SXGA / XGA / SVGA / VGA / MAC compatibility with one M1-DA input terminal
- Auto image re-sizing to 1024 x 768 full screen
- Auto detection of computer signal input
- Auto Image synchronization (Auto-tracking / frequency / position adjustment)
- Powerful enlarge and freeze function
- Automatically saves adjustments for future use
- On-screen menu with up to 10 languages
- Built-in one speaker with 2 Watt amplifier
- Self protect timer for hot re-strike of compact P-VIP lamp
- Wireless remote control with USB mouse function and laser pointer
- Adaptive voltage control fan speed
- Noise : Expect Marketing spec - 32dB(A) (30 min)  
Real Engineering spec - Max 37 dB(A) (1hr) => Same as H55.
- Build-in full screen NTSC / PAL / SECAM video capability with S-video / Composite / Component and HDTV terminals

## 1-2 Technical Specifications

### 1-2.1 Optical Features

<b>Projection Lens</b>	F/2.44~2.69, f=28.8~34.5mm. 1.2X Manual Zoom Lens
<b>Projection Image Size</b>	Adjustable from 23.4" to 295.3" (Diagonal) (Suggested Projection Image Size : 36.9"~245.9")
<b>Throw Distance</b>	1.4m~12m (Suggested throw distance : 1.5~10m) (Marketing Spec. - 1.14m~12m)
<b>Brightness</b>	1300 ANSI Lumens (Marketing) 1150 ANSI Lumens (Average) 1000 ANSI Lumens (Minimum)
<b>Contrast</b>	1600 : 1 Marketing (Full White and Black) 1450 : 1 Typical (Full White and Black) 1300 : 1 Minimum (Full White and Black)
<b>Uniformity</b>	85% Marketing (Japan Standard) 75% Typical (Japan Standard) 65% Minimum (Japan Standard)
<b>Color Temperature</b>	7500°K (Default) 7000 to 8800°K (Min. to Max.)

## 1-2.2 Electrical Features

<b>Power Supply</b>	<ul style="list-style-type: none"> <li>- Universal AC 100-240V ~ 50/60Hz with PFC input</li> <li>- (Wattage to be determinate) for 150W Compact P-VIP Lamp@normal operation</li> <li>- Variance FAN speed control (Depend on temperature variant)</li> </ul>
<b>Power Consumption</b>	<ul style="list-style-type: none"> <li>- 190 Watt +/- 10% at normal operation</li> <li>- Standby mode &lt; 35W</li> </ul>
<b>Terminals</b>	<ul style="list-style-type: none"> <li>- Computer Input (VESA M1-DA Female Terminal x 1)</li> <li>- Composite Video Input (RCA jack x 1)</li> <li>- S Video Input (Mini DIN 4-pin x 1)</li> <li>- Audio line Input (3.5mm phone jack x 1)</li> <li>- Monitor Output (D-Sub 15-pin female terminal x 1)</li> </ul>
<b>Input signal spec.</b>	<ul style="list-style-type: none"> <li>- Hsync Frequency 15 ~ 100 kHz</li> <li>- Vsync Frequency 43 ~ 120 Hz</li> <li>- Video Signal RGB (PC)</li> <li>- Analog RGB 0.7Vp-p, 75 ohm</li> <li>- Analog RGB 1Vp-p, 75 ohm, Sync. signal</li> <li>- Separate TTL H, V Sync.</li> <li>- Composite TTI Sync.</li> <li>- Video</li> <li>- Composite video 1Vp-p, 75 ohm</li> <li>- S-video Luminance 0.714Vp-p, 75 ohm</li> <li>- Chrominance 0.286Vp-p, 75 ohm</li> </ul>
<b>Video Compatibility</b>	<ul style="list-style-type: none"> <li>- Standards :</li> <li>- NTSC - M(3.58 MHz), 4.43 MHz,</li> <li>- PAL - B, D, G, H, I, M, N</li> <li>- SECAM - B, D, G, K, K1, L</li> <li>- HDTV - 480i; 480P; 720P; 1080i</li> </ul>
<b>Audio</b>	<ul style="list-style-type: none"> <li>- One 4-Ohm, 2W, internal speaker</li> <li>- 2 Watts amplifier</li> <li>- Input sensitivity 0.3Vrms.</li> </ul>

### 1-2.3 Mechanical Features

<b>Dimensions (W x H x D)</b>	- 9.68 x 8.05 x 2.8 +/- 0.034 inches (246 x 204.4 x 71.2 +/- 1mm, w/o lens) - 9.68 x 8.73 x 3.1 +/- 0.034 inches (246 x 221.7 x 78.6 +/- 1mm, with lens)
<b>Weight</b>	Approx. 3.9 lbs.
<b>Tilt Angle</b>	8 degree with elevator mechanism
<b>Keystone correction</b>	+/- 16 degree (32 degree)
<b>Lamp Door Protection</b>	Lamp power supply shut off automatically when door open

### 1-2.4 Environmental Features

<b>Temperature</b>	Operating : 10~40°C Storage : -20~60°C
<b>Maximum Humidity</b>	Operating : 10~40°C, 80%RH(Max.), non-condensing\ Storage : -20~60°C, 80%RH (Max.), non-condensing
<b>Acoustic noise level</b>	32 dBA (expect marketing spec.) 35 dBA (Typical, Under 25°C) 37 dBA (Max., Under 25°C)
<b>Lamp Life</b>	1,500 hours marketing 1,200 hours typical, 50% survival rate
<b>Altitude</b>	- Operating : 0~2,500 ft 10°C~40°C 2,500~5,000 ft 10°C~35°C 5,000~10,000 ft 10°C~25°C - Storage : 40,000 ft
<b>MTBF</b>	Operating more than 12,000 hours (90% Confidence Level)




# Fundamental Principle


# 2

This section provides the conceptual drawing about optics of projector. You can realize optical projection system through the following diagram and the integral part of configuration, too.


## 2-1 Function Block Diagram




## 2-1.1 Main Board Block Diagram



## 2-1.2 DMD Board Block Diagram




### 2-1.3 Thermal Board Block Diagram



## 2-2 Optics

### 2-2.1 Conceptual Drawing



1. 150W P-VIP Lamp
2. Color Wheel
3. Hollow Rod
4. Condenser Lens

5. Mirror 2
6. Mirror 1
7. Relay Lens
8. DMD Module

## 2-2.2 Basic Functions

<b><i>150W P-VIP Lamp</i></b>	The light source.
<b><i>Color Wheel</i></b>	Separating the light beam into and produce R.G.B colors.
<b><i>Hollow Rod</i></b>	Making the light beam uniform.
<b><i>Condenser Lens</i></b>	Condensing the light beam.
<b><i>Mirror</i></b>	Folding optical path.
<b><i>DMD Module</i></b>	Displaying component.


# Mechanical Construction

# 3

This section provides the package and exploded overview, replaceable parts list and recommendation parts list for the portable projector. You can place an order for correct parts in the recommendation parts list.




## 3-1 Package Overview



### Replacement Parts List


Item	P/N	Rev.	Description
	AK.86301.001	A	PIZZA BOX MODULE FOR EP737
1	36.00012.002	B	WARRANT CARD, US FOR LPP SERIES
2	36.00018.001	A	EXTENDED WARRANTY ;REGISTRATION FORM,USA FOR LPP SERIES
3	36.86301.001	A	QUICK START CARD MULTILINGUAL EP737
4	42.86301.001	A	CABLE RS-232(BLUE) TO MINI DIN 3PIN 1800mm EP737
5	42.50110.011	A	CABLE RCA 1.8M XB31
6	42.50209.031	A	CABLE S-VIDEO 1.8M XB31
7	42.85804.001	A	CABLE M1-A TO VGA/USB(A) 1.8M MOLEX
8	42.85811.001	A	CABEL MINI JACK TO MINI JACK 1.8M BLACK XB31
9	36.86302.001	A	USER'S GUIDE FOR EP737
10	46.80301.001	B	BATTERY #4 1.5V
11	55.83302.001	A	CARTON ACCESSORY BOX EzPro 730
12	56.86301.001	A	PARTITION FOR ACCESSORY BOX EPE EP737
13	70.83443.001	A	ACCESSORY REMOTE CONNTROLLER EzPro 735(OPTOMA LABEL)



## Replacement Parts List

Item	P/N	Rev.	Description
	SP.86303.001	A	CEILING MOUNT CONNECTOR AND CABLE EP737
1	35.52302.091	A	LABEL CARTON 108*92 BLANK
2	36.86303.001	A	CEILING MOUNT MANUAL EP737
3	51.52121.001	A	PEBAG ZIPPER #3 100*70*0.04 LMT-5020
4	51.80725.001	A	PE BAG 20*20*50CM U TYPE
5	55.80706.001	A	CARTON AB 20*20*48CM FOR CEILING MOUNT
6	56.86303.001	A	CUSHION BOTTOM FOR CEILING MOUNT EPE EP737
7	56.85809.001	A	CUSHION TOP FOR CEILING MOUNT EPE XB31
8	61.80726.001	A	SCREW/NUT 5/16 INCH STRUCTURE
9	75.86307.001	A	ASSY CEILING MOUNT MODULE EP737
10	85.1A523.060	A	SCREW PAN MECH M3*6 Ni NYLOK
11	42.50209.021	A	CABLE S-VHS 5M EzPro 600
12	42.86305.001	A	CABLE M1-A TO VGA/USB(A) 5M MOLEX EP737
13	42.80715.011	A	CABLE MINI JACK TO RCA 5M

## 3-2 Exploded Overview




## Replacement Parts List

Item	P/N	Rev.	Description
	DC.86301.001	A	D.C. EP737
1	42.85802.002	A	W.A. 14 #26 50mm UL1061 THERMAL-BD/BALLAST XB31
2	42.85803.001	A	W.A. 4P #22 185mm DC-DC/BALLAST XB31
3	42.85809.001	A	W.A. 3P #28 125mm BALLAST/THERMAL BD
4	51.00071.001	A	SPACER SUPPORT PG-MCF-6 XB31
5	51.86301.001	A	LAMP BOTTOM COVER NORYL N300X EP737
6	61.00018.002	A	LOCK SCREW PAN MECH M3*8.5-3.5 B
7	61.86302.001	A	FAN GUIDE BRACKET AL 5052 EP737
8	61.86304.001	A	OPTOMA LOGO AL EP737
9	70.86301.001	A	ASSY TOP COVER MODULE EP737
10	70.86302.001	A	ASSY BOTTOM COVER MODULE EP737
11	70.86303.001	A	ASSY FRONT COVER MODULE EP737
12	70.86305.001	A	ASSY RIGHT COVER MODULE EP737
13	70.86306.001	A	ASSY LEFT COVER MODULE EP737
14	70.86307.001	A	ASSY ENGINE MODULE EP737
15	75.86302.001	A	BUY ASSY FOCUS RING FRONT EP737
16	80.86302.001	E	PCBA THERMAL BOARD EP737
17	85.1A626.050	A	SCREW PAN MECH M2.6*5 BLACK NYLOK
18	85.1A623.060	A	SCREW MACHINE PAN M3*6 NYLOK VX3600
19	70.86315.001	A	ASSY PCBA MAIN BOARD MODULE EP737
20	70.86308.001	A	ASSY LAMP MODULE EP737
21	70.86309.001	A	FAN 50-15 MODULE EP737
22	70.86318.001	A	FAN FAL3F PANASONIC MODULE EP737

Item	P/N	Rev.	Description
23	70.85810.001	A	DC_DC MODULE XB31
24	85.00025.041	A	HEX I/O M2.5*H6.6*L4.0 BRASS
25	52.86309.001	A	MAIN BOARD BOTTOM RUBBER EP737
26	61.86317.001	A	SAFE BRAKE FOR LAMP GAP SUS304 EP737
27	85.1A525.040	A	SCREW PAN MECH M2.5*4 Ni NLK


### 3-2.1 Fan 50-15 Module



#### Replacement Parts List

Item	P/N	Rev.	Description
	70.86309.001	A	FAN 50-15 MODULE EP737
1	49.86304.001	A	MISC FAN SUNON 5015 L=70mm EP737
2	52.86303.001	A	FAN RUBBER SUNON 5015 RUBBER EP737
3	61.86316.001	A	FAN BRACKET SUNON 5015 SUS304 EP737


## 3-2.2 Top Cover Module



### Replacement Parts List

Item	P/N	Rev.	Description
	70.86301.001	A	ASSY TOP COVER MODULE EP737
1	61.86303.001	A	TOP COVER Mg ALLOY AZ-91D EP737
2	51.86302.001	A	KEY PAD PC+ABS C6200 EP737
3	51.86303.001	A	LED LENS PC EP737
4	80.86303.001	D	PCBA KEYPAD BOARD EP737
5	42.85801.001	A	CABLE FFC 14P 0.5Pitch 140mm KEY BD/FRONT END BD XB31
6	85.1A626.050	A	SCREW PAN MECH M2.6*5 BLACK NYLOK
7	52.86304.001	A	TOP SEALING SPONGE PORON EP737
8	61.86311.001	A	TOP COVER EMI SPRING EP737
9	55.86301.001	A	HEAT INSULATION PAD EP737
10	51.00068.001	A	NYLON WASHER PG U-5 FOR BALLAST XB31
11	61.86314.001	A	LIGHT CUT UP FOR LAMP MODULE AL EP737
12	85.1G923.064	A	PLASTIC SCREW M3.0*6.4 PG S-306-N66 XB31

### 3-2.3 Bottom Cover Module




## Replacement Parts List

Item	P/N	Rev.	Description
	70.86302.001	A	ASSY BOTTOM COVER MODULE EP737
1	51.00068.001	A	NYLON WASHER PG U-5 FOR BALLAST XB31
2	51.00075.001	A	WIRE MOUNTS PG-FW-4D XB31
3	51.85803.002	A	ADJUST FOOT PC+ABS C6200 CS-SA05A SB21
4	51.86304.001	A	ELEVATOR FOOT NORYL N300X EP737
5	51.86305.001	A	ELEVATOR HOOK NORYL N300X EP737
6	52.85801.001	A	RUBBER-FOOT D=16.0mm 2.5t XB31
7	52.86311.001	A	DMD HEATSINK THERMAL PAD 14*35*1t EP737
8	52.85818.001	A	LEFT RUBBER FOOT D=16.0mm 4.0t XB31
9	61.00022.001	A	SELF-LOCKING RING (SPN ϕ1.5)
10	61.86305.001	A	BOTTOM COVER Mg ALLOY AZ-91D EP737
11	61.86306.001	A	BOTTOM COVER MESH IRON NET EP737
12	61.86307.001	A	ELEVATOR BRACKET SUS304 EP737
13	61.86308.001	A	ELEVATOR FOOT SPRING SUS301 EP737
14	61.86309.001	A	ELEVATOR PUSH SPRING SUS301 EP737
15	52.86305.001	A	ELEVATOR FOOT RUBBER EP737
16	52.86306.001	A	BTM SEALING SPONGE PORON EP737
17	75.86305.001	A	ASSY LIMIT SWITCH CHERRY DB1C A1LB-5A EP737
18	70.86311.001	A	BALLAST MODULE EP737
19	85.00025.041	A	HEX IO M2.5*H6.6*L4.0 BRASS
20	85.1A626.050	A	SCREW PAN MECH M2.6*5 BLACK NYLOK

Item	P/N	Rev.	Description
21	85.1C224.050	A	SCREW PAN MECH M4*5 COLOR W/TOOTH WASHER
22	85.1D122.050	A	SCREW PAN MECH M2*5 Ni (W/WASHER ϕ5.0)
23	85.1G923.064	A	PLASTIC SCREW M3.0*6.4 PG S-306-N66 XB31
24	51.86319.001	A	BALLAST MYLAR FRPP EP737
25	51.86323.001	A	LIMIT SWITCH HOLDER NORYL N300X EP737
26	86.00122.015	A	NUT HEX M2.0*0.4P L1.5 Ni
27	52.86308.001	A	LENS STAND PAD EP737




### 3-2.4 Main Board Module



### Replacement Parts List

Item	P/N	Rev.	Description
	70.86315.001	A	ASSY PCBA MAIN BOARD MODULE EP737
1	80.86301.001	E	PCBA MAIN BOARD EP737
2	75.86303.001	A	BUY ASSY IO BEZEL MODULE EP737
3	85.005AG.040	A	SCREW I/O STEEL #4-40UNC*H4*L5.5 NYLOK
4	52.86309.001	A	MAIN BOARD BOTTOM RUBBER EP737


### 3-2.4 Front Cover Module



#### Replacement Parts List

Item	P/N	Rev.	Description
	70.86303.001	A	ASSY FRONT COVER MODULE EP737
1	75.86301.001	A	BUY FRONT COVER MODULE EP737
2	76.86301.001	A	ASSY IR-SENSOR 3P #28 UL1007 160mm Green EP737
3	51.86321.001	A	IR COVER PAD FRONT EP737
4	70.86304.001	A	ASSY FRONT FAN MODULE EP737
5	85.1A626.050	A	SCREW PAN MECH M2.6*5 BLACK NYLOK


### 3-2.5 ASSY Front Fan Module



#### Replacement Parts List

Item	P/N	Rev.	Description
	70.86304.001	A	ASSY FRONT FAN MODULE EP737
1	52.86301.001	A	FAN RUBBER FRONT COVER RUBBER EP737
2	49.86301.001	A	MISC FAN SUNON 5010 L=300mm EP737
3	49.86303.001	A	MISC FAN SUNON 5015 L=250mm EP737
4	51.86307.001	A	FAN HOLDER FRONT COVER NORYL EP737
5	51.86322.001	A	FAN GUIDE FRONT NORYL N300X EP737
6	85.1A626.050	A	SCREW PAN MECH M2.6*5 BLACK NYLOK


### 3-2.6 ASSY Right Cover Module



#### Replacement Parts List

Item	P/N	Rev.	Description
	70.86305.001	A	ASSY RIGHT COVER MODULE EP737
1	51.86311.001	A	RIGHT COVER PC+ABS C6200 EP737
2	75.86306.001	A	ASSY SPEAKER RUBBER PAD-FIBER EP737
3	49.86302.001	A	SPEAKER 2W 40hm 51*20.1*13.1mm 80mml
4	85.1D122.050	A	SCREW PAN MECH M2*5 Ni (W/WASHER φ5.0)


### 3-2.7 BUY Front Cover Module



#### Replacement Parts List

Item	P/N	Rev.	Description
	75.86301.001	A	BUY FRONT COVER MODULE EP737
1	51.86308.001	A	ELEVATOR PUSH BUTTOM PC+ABS C6200 EP737
2	51.86310.001	A	IR LENS FRONT PC 1225Y EP737
3	51.86309.001	A	FRONT COVER NORYL N300X EP737


### 3-2.8 ASSY Left Cover Module



#### Replacement Parts List

Item	P/N	Rev.	Description
	70.86306.001	A	ASSY LEFT COVER MODULE EP737
1	51.86312.001	A	LEFT COVER NORLY N300X EP737
2	53.86302.001	A	NOISE ELIMINATING PAD FRONT EP737
3	53.86303.001	A	NOISE ELIMINATING PAD BACK EP737


### 3-2.8 Lamp Module



### Replacement Parts List

Item	P/N	Rev.	Description
	70.86308.001	A	ASSY LAMP MODULE EP737
1	23.85815.001	A	OSRAM 150W 1.3MM ARC P16 REFLECTOR
2	51.86315.001	A	LAMP HOLDER BOTTOM PPS EP737
3	61.00018.002	A	LOCK SCREW PAN MECH M3*8.5-3.5 B
4	61.83109.001	A	LAMP EXCHANGE HANDLER
5	61.85804.001	A	LAMP HOLDER Mg ALLOY , XB31
6	61.86313.001	A	LIGHT CUT FOR LAMP MODULE AL EP737
7	61.86315.001	A	LIGHT CUT DOWN FOR LAMP MODULE AL EP737
8	85.1A321.030	A	SCREW PAN MECH M1.7*3 BLACK
9	85.41623.050	A	SCREW FLAT M3*5 BLACK NYLOK SOCKET
10	86.0A123.024	A	HEX NUT M3*0.5P L2.4 Ni
11	85.1A626.050	A	SCREW PAN MECH M2.6*5 BLACK NYLOK

## 3-2.9 Engine Module




### Replacement Parts List

Item	P/N	Rev.	Description
	70.86307.001	A	ASSY ENGINE MODULE EP737
1	61.85815.001	A	SHOULDER SCREW FOR DMD XB31
2	52.85806.001	A	RUBBER WASHER FOR DMD XB31
3	61.86312.001	A	DMD-HEATSINK ADC12 EP737
4	52.85810.001	A	DMD HEATSINK THERMAL PAD 19*14*1t
5	51.86328.001	A	DMD-HEAT-SINK-INSULATOR MYLAR EP737
6	80.86304.001	A	PCBA DMD BOARD EP737
7	75.85803.001	A	CONTACT HOUSING INTERCON 7502-001 FOR DDR 0.7" XGA XB31
8	48.858DM.D11	A	DMD 1024*768 P*EL DDR 0.7" XGA
9	51.85814.001	A	DMD HOLDER DDR 07 ULTEM 2300 XB31
10	52.85802.001	A	DMD-LIGHT-MASK XB31 RUBBER
11	70.86312.001	A	ENGINE SUB MODULE EP737
12	52.85819.001	A	TUBE COLOR WHEEL, SUMITUBE F32,BLACK
13	52.86310.001	A	DMD FAN INSULATOR RUBBER EP737




### 3-2.10 Engine SUB Module



### Replacement Parts List

Item	P/N	Rev.	Description
	70.86312.001	A	ENGINE SUB MODULE EP737
1	23.85802.001	A	SILFLEX-VIS MIRROR 1
2	23.85802.011	A	SILFLEX-VIS MIRROR 2
3	23.85806.001	A	ASPHERIC CONDENSER B270 LENSφ28MM
4	23.85806.011	A	ASPHERIC TRUNCATE RELAY LENS φ46MM
5	51.85815.001	A	ENGINE BOTTOM BMC , XB31
6	52.85808.001	A	PORON-LENS BLACK XB31
7	52.85816.001	A	RUBBER-ANTI-DUST BLACK XB31
8	61.85805.001	A	ROD SPRING SUS301 0.2t , XB31
9	61.85806.001	A	MIRROR1 SPRING SUS301 0.25t , XB31
10	61.85807.001	A	MIRROR2-SPRING SUS301 0.25t, XB31
11	70.86310.001	A	OPTICAL ZOOM LENS MODULE EP737
12	70.85822.001	A	ENGINE PRE-ASSY MODULE XB31
13	70.86313.001	A	COLOR WHEEL MODULE EP737
14	70.85824.001	A	ROD MODULE XB31
15	76.85802.001	B	ASSY PHOTO-SENSOR-BD UL1007 #28 170mm Blue XB31
16	85.1A525.060	A	SCREW PAN MECH M2.5*6 Ni NYLOK CARUSO
17	85.1A626.050	A	SCREW PAN MECH M2.6*5 BLACK NYLOK


### 3-2.11 ENGINE PRE-ASSY MODULE



#### Replacement Parts List

Item	P/N	Rev.	Description
	70.86316.001	A	ENGINE PRE-ASSY MODULE EP737
1	61.85803.001	A	ENGINE TOP MG ALLOY , XB31
2	23.85810.001	A	PYREX UV-IR FILTER $\phi$ 16.750.25MM
3	61.81517.001	A	BRACKET for UV-IR FILTER
4	85.4A622.030	A	SCREW FLAT MECH M2*3 BLACK NYLOK CARUSO
5	43.86317.001	A	THERMAL SWITCH WITH BRACKET KLIXON
6	85.1A626.050	A	SCREW PAN MECH M2.6*5 BLACK NYLOK


### 3-2.12 Optical Zoom Lens Module



#### Replacement Parts List

Item	P/N	Rev.	Description
	70.86310.001	A	OPTICAL ZOOM LENS MODULE EP737
1	23.81901.003	A	OPTICAL ZOOM LENS OF NEW COATING 0.7"DMD CARUSO
2	70.86314.001	A	ASSY ZOOM RING MODULE EP737
3	51.86313.001	A	FOCUS RING BASE PC+ABS C6200 EP737
4	85.4A622.030	A	SCREW FLAT MECH M2*3 BLACK NYLOK CARUSO
5	85.YA121.025	A	SCREW FLAT HEAD TAP M1.7*2.5 Ni


### 3-2.13 ASSY ZOOM RING MODULE



#### Replacement Parts List

Item	P/N	Rev.	Description
	70.86314.001	A	ASSY ZOOM RING MODULE EP737
1	51.86314.001	A	ZOOM RING PC+ABS C6200 EP737
2	52.86307.001	A	ZOOM RING RUBBER EP737


### 3-2.14 ASSY FOCUS RING FRONT



#### Replacement Parts List

Item	P/N	Rev.	Description
	75.86302.001	A	BUY ASSY FOCUS RING FRONT EP737
1	51.86316.001	A	FOCUS RING PC+ABS C6200 EP737
2	51.86317.001	A	FOCUS RING SUIT PC+ABS C6200 EP737


### 3-2.15 BUY ASSY LENS COVER



#### Replacement Parts List

Item	P/N	Rev.	Description
	75.86304.001	A	BUY ASSY LENS COVER EP737
1	51.86320.001	A	LENS COVER PC+ABS C6200 EP737
2	51.86306.001	A	LENS COVER SPRING PC EP737
3	51.83150.001	A	CAP STRAP


### 3-2.16 Color Wheel Module



#### Replacement Parts List

Item	P/N	Rev.	Description
	70.86313.001	A	COLOR WHEEL MODULE EP737
1	23.85819.011	A	R90G100W85B85 DDR CW (MOTOR20.5MM)
2	61.86310.001	A	COLOR WHEEL HOLDER SECC 1.2t EP737
3	52.83615.001	A	COLORWHEEL DISC RUBBER,EzPro755
4	61.83628.001	A	COLORWHEEL SHOULDER SCREW,EzPro755

### 3-2.17 ROD MODULE



#### Replacement Parts List

Item	P/N	Rev.	Description
	70.86317.001	A	ROD MODULE EP737
1	23.85817.011	A	HLE HOLLOW ROD 6.75*4.9*24.2 MMN3
2	61.85823.001	A	ROD HOLDER SUS 301 0.2t



### 3-3 Recommendation Spare Parts List

Item	P/N	Rev.	Description	Type
1	35.52302.091	A	LABEL CARTON 108*92 BLANK	CM
2	35.86301.001	A	SPEC LABEL BLANK EP737	CM
3	36.00018.001	A	EXTENDED WARRANTY ;REGISTRATION FORM,USA FOR LPP SERIES	CM
4	36.86301.001	A	QUICK START CARD MULTILINGUAL EP737	CM
5	36.86302.001	A	USER'S GUIDE FOR EP737	CM
6	42.50110.011	A	CABLE RCA 1.8M XB31	CM
7	42.50209.031	A	CABLE S-VIDEO 1.8M XB31	CM
8	42.81505.051	A	CABLE POWER-CORD AC C5 3P#18/SPT-2 UNSHLD 6ft BLACK(N,A);XB31	CM
9	76.81904.001	A	ASSY FAN FAL3F12LH 50*20 CARUSO	CM
10	42.86301.001	A	CABLE RS-232(BLUE) TO MINI DIN 3PIN 1800mm EP737	CM
11	42.85804.001	A	CABLE M1-A TO VGA/USB(A) 1.8M MOLEX	CM
12	42.85811.001	A	CABEL MINI JACK TO MINI JACK 1.8M BLACK XB31	CM
13	42.85802.002	A	W.A. 14*26 50mm UL1061 THERMAL BD/BALLAST XB31	CM
14	42.85803.001	A	W.A. 4P #22 185mm DC-DC/BALLAST XB31	CM
15	42.85808.001	A	W.A. GROUND FOR BALLAST 135mm XB31	CM
16	42.85801.001	A	CABLE FFC 14P 0.5Pitch 140mm KEY BD/FRONTEND BD XB31	CM
17	42.85809.001	A	W.A. 3P #28 125mm BALLAST/THERMAL BD	CM
18	42.83603.001	A	CABLE M1-D TO DVI/USB(A) 5M MOLEX EP737	CM
19	42.83604.001	A	CABLE M1-A TO HDTV/USB(A) 5M MOLEX EP737	CM
20	48.858DM.D11	A	DMD 1024*768 P*EL DDR 0.7" XGA	SW
21	49.81901.001	A	PANASONIC SCIROCCO FAN FAL3F12LH 50*20mm	CM

Item	P/N	Rev.	Description	Type
22	49.86301.001	A	MISC FAN SUNON 5010 L=300mm EP737	CM
23	49.86302.001	A	SPEAKER 2W 40hm 51*20.1*13.1mm 80mm	CM
24	49.86304.001	A	MISC FAN SUNON 5015 L=70mm EP737	CM
25	51.00061.001	A	PLASTIC RIVET $\phi$ 3.0 SR-3L	CM
26	51.00068.001	A	NYLON WASHER PG U-5 FOR BALLAST XB31	CM
27	51.00071.001	A	SPACER SUPPORT PG-MCF-6 XB31	CM
28	51.81537.001	A	ESD BAG LDPE 300*400*0.1mm	CM
29	51.83138.001	A	DC TO DC BOARD HOLDER	CM
30	51.83142.001	A	FUSE COVER (FH-1L-UL)	CM
31	51.85814.001	A	DMD HOLDER DDR 07 ULTEM 2300 XB31	CM
32	51.85827.001	A	DC_DC_BD MYLAR 0.5t XB31 Black	CM
33	51.85828.001	A	DMD-HEAT-SINK-INSULATOR MYLAR XB31	CM
34	51.86301.001	A	LAMP BOTTOM COVER NORYL N300X EP737	CM
35	51.86302.001	A	KEY PAD PC+ABS C6200 EP737	CM
36	51.86303.001	A	LED LENS PC EP737	CM
37	51.86304.001	A	ELEVATOR FOOT NORYL N300X EP737	CM
38	51.86305.001	A	ELEVATOR HOOK NORYL N300X EP737	CM
39	51.86311.001	A	RIGHT COVER PC+ABS C6200 EP737	CM
40	51.86319.001	A	BALLAST MYLAR FRPP EP737	CM

Item	P/N	Rev.	Description	Type
41	51.86321.001	A	IR COVER PAD FRONT EP737	CM
42	51.86323.001	A	LIMIT SWITCH HOLDER NORYL N300X EP737	CM
43	51.86325.001	A	ENGINE LIGHT CUT MYLAR C850PVC 0.1t	CM
44	51.86326.001	A	FAN FAL3F DUCT FRONT PPS EP737	CM
45	51.86327.001	A	FAN FAL3F DUCT BACK PPS EP737	CM
46	51.86307.001	A	FAN HOLDER FRONT COVER NORYL EP737	CM
47	51.86322.001	A	FAN GUIDE FRONT NORYL N300X EP737	CM
48	52.85802.001	A	DMD-LIGHT-MASK XB31 RUBBER	CM
49	52.85806.001	A	RUBBER WASHER FOR DMD XB31	CM
50	52.85810.001	A	DMD HEATSINK THERMAL PAD 19*14*1t	CM
51	52.85812.001	A	LOCK_RUBBER FOR FAN_FAL3F_DUCT XB31	CM
52	52.85814.001	A	WASHER RUBBER FOR FAN_PANASONIC XB31	CM
53	52.85819.001	A	TUBE COLOR WHEEL, SUMITUBE F32,BLACK	CM
54	52.86303.001	A	FAN RUBBER SUNON 5015 RUBBER EP737	CM
55	52.86305.001	A	ELEVATOR FOOT RUBBER EP737	CM
56	52.86309.001	A	MAIN BOARD BOTTOM RUBBER EP737	CM
57	52.86310.001	A	DMD FAN INSULATOR RUBBER EP737	CM
58	52.86301.001	A	FAN RUBBER FRONT COVER RUBBER EP737	CM
59	53.86304.001	A	SOFT CARRY BAG EP737	CM
60	55.83601.002	A	CARTON AB 424*384*322 EP755	CM

Item	P/N	Rev.	Description	Type
61	56.86301.001	A	PARTITION FOR ACCESSORY BOX EPE EP737	CM
62	56.86302.001	A	CUSHION EPE EP737	CM
63	57.00001.001	A	PACK SIO2 DRIER 20g	CM
64	61.00018.002	A	LOCK SCREW PAN MECH M3*8.5-3.5 B	CM
65	61.86302.001	A	FAN GUIDE BRACKET AL 5052 EP737	CM
66	61.85815.001	A	SHOULDER SCREW FOR DMD XB31	CM
67	61.86304.001	A	OPTOMA LOGO AL EP737	CM
68	61.86307.001	A	ELEVATOR BRACKET SUS304 EP737	CM
69	61.86308.001	A	ELEVATOR FOOT SPRING SUS301 EP737	CM
70	61.86309.001	A	ELEVATOR PUSH SPRING SUS301 EP737	CM
71	61.86312.001	A	DMD-HEATSINK ADC12 EP737	CM
72	61.86314.001	A	LIGHT CUT UP FOR LAMP MODULE AL EP737	CM
73	61.86316.001	A	FAN BRACKET SUNON 5015 AL EP737	CM
74	70.86306.001	A	ASSY LEFT COVER MODULE EP737	CM
75	70.86319.001	A	ASSY TOP COVER MODULE EP737 (RMA)	SW
76	70.86320.001	A	ENGINE SUB MODULE EP737 (RMA)	SW
77	70.86321.001	A	ASSY BOTTOM COVER MODULE EP737 (RMA)	SW
78	70.86313.001	A	COLOR WHEEL MODULE EP737	SW
79	75.85803.001	A	CONTACT HOUSING INTERCON 7502-001 FOR DDR 0.7" XGA XB31	CM
80	75.85813.001	A	ASSY DC TO DC BOARD XB31	SW
81	75.86304.001	A	BUY ASSY LENS COVER EP737	CM
82	75.86305.001	A	ASSY LIMIT SWITCH CHERRY DB1C A1LB-5A EP737	CM
83	75.85801.001	B	ASSY BALLAST+PFC XB31	SW

Item	P/N	Rev.	Description	Type
84	75.86301.001	A	BUY FRONT COVER MODULE EP737	CM
85	75.86303.001	A	BUY ASSY IO BEZEL MODULE EP737	CM
86	75.86306.001	A	ASSY SPEAKER RUBBER PAD-FIBER EP737	CM
87	76.85802.001	B	ASSY PHOTO-SENSOR-BD UL1007 #28 170mm Blue XB31	CM
88	76.86301.001	A	ASSY IR-SENSOR 3P#28 UL1007 160mm Green EP737	CM
89	80.86301.001	E	PCBA MAIN BOARD EP737	SW
90	80.86302.001	E	PCBA THERMAL BOARD EP737	SW
91	80.86303.001	D	PCBA KEYPAD BOARD EP737	SW
92	80.86304.001	A	PCBA DMD BOARD EP737	SW
93	85.005AG.040	A	SCREW I/O STEEL	CM
94	85.00025.041	A	HEX I/O M2.5*H6.6*L4.0 BRASS	CM
95	85.1A626.050	A	SCREW PAN MECH M2.6*5 BLACK NYLOK	CM
96	85.1A525.040	A	SCREW PAN MECH M2.5*4 Ni NLK	CM
97	85.1A623.060	A	SCREW MACHINE PAN M3*6 NYLOK VX3600	CM
98	SP.86301.001	A	CEILING MOUNT CONNECTOR EP737	CM
99	SP.86302.001	A	LAMP REPLACE MODULE FOR EP737	CM
100	SP.86303.001	A	CEILING MOUNT CONNECTOR AND CABLE EP737	CM

### Note :

SW = Swap Spare Parts, CM = Consume Spare Parts. You can place an order for swap or consume spare parts to do replacement. Or just return swap spare parts back for repair, but consume spare parts is not acceptable for repair or return.

SW is repairable, when it's defective please return back the defective but complete parts to swap for good parts. Regarding CM, it's not repairable and you should give the order to do replacement and discard the defective parts directly.

The recommendation spare parts list is built for the convenience of disassembly procedure. If there is any comment or recommendation on the item of SW or CM, please let us know.

# Procedure Of Disassembly

# 4

This section provides disassembly procedures for EP737 Micro Portable XGA DLP Projector. Before you begin any of these procedures, be sure to turn off the power, computer system, and other attached devices; then disconnect the power cable from the electronically outlet. Moreover, when you disassemble the projector, be sure to put the screws in a safe place and separate them according to grouping.

## Tools Needed :



Long Nose Nipper



Screw Bit (+) : 101



Hex Sleeves 5mm




Screw Bit (+) : 102



Screw Bit (+) : 107

## 4-1 Disassemble Lamp Module




1. Loosen two screws of Lamp Bottom Cover to remove Lamp Bottom Cover.
2. Loosen two screws of Lamp Module to pull out Lamp Module.



## 4-2 Disassemble Top Cover and Keypad Board




1. Remove five screws of Bottom Cover.
2. Remove one screw beside Right Cover.
3. Remove one screw beside Left Cover.
4. Turn over the projector, then lift up Top Cover from Left and Right side.
5. Unplug FFC from Main Board to remove Top Cover.




6. Unscrew four screws to remove Keypad Board and Keypad
7. Unplug FFC from Keypad Board.
8. Separate Keypad Board, Keypad and LED Lens.
9. Unscrew two screws to remove Light Cut Up.

## 4-3 Disassemble Left Cover, Right Cover and I/O Bezel Module




1. Remove four hex screws to remove I/O Bezel Module.
2. Unscrew one screw to remove Left Cover.




3. Unplug one wire from Main Board and unscrew one screw to remove Right Cover.
4. Remove two screws to take off speaker from Right Cover.

## 4-4 Disassemble Front Cover





1. Pull out Focus Ring from Front Cover Module.
2. Unscrew three screws from Front Cover Module and unplug three wires from Thermal Board  
Take off Front Cover Module from Bottom Cover Module.




3. Unscrew four screws from Front Cover and take off it.
4. Unscrew three screws from Fan Guide to remove it.
5. Tear off IC Cover Pad, pull up IR Sensor Board from Front Cover Module.

## 4-5 Disassemble Thermal Board and Main Board




1. Unscrew two screws to remove Fan Guide Bracket.
2. Unscrew one screw and unplug five wires from Thermal Board to remove it.




3. Unscrew two hex screws and two screws from Main Board.
4. Pull up Main Board and Separate Main Board and Main Board Bottom Rubber.



## 4-6 Disassemble Ballast and Fan Module




1. Unscrew two screws from Engine Module and pull out the Ignite Wire.
2. Unscrew two long hex screws and one plastic screw from Ballast Module.
3. Unscrew one screw from grounding then pull put the Ballast Module.




4. Unscrew four screws to remove two Fan Module from Bottom Module.

## 4-7 Disassemble DC-DC Board and Interlock Switch




1. Unplug one wire from DC-DC Board.  
Unscrew one screw to remove DC-DC Module from Bottom Cover.
2. Unscrew one screw to remove Interlock Switch from Bottom Cover.

## 4-8 Disassemble Engine, DMD and DMD Board




1. Unscrew four screws to remove Engine Module




2. Unscrew four shoulder screws and Rubber Washers to remove DMD Heatsink, DMD Board, and Contact Housing Intercon.
3. Remove DMD from DMD Holder.

## 4-9 Disassemble Color Wheel, Photo Sensor Board and Thermal Switch



1. Unscrew one screw to remove Color Wheel and Photo Sensor Board from Engine.
2. Unscrew one screw to remove Photo Sensor Board from Color Wheel Holder.
3. Unscrew one screw to remove Thermal Switch from Engine.

## 4-10 Disassemble Elevator Module



1. Unscrew two screws to remove Elevator Bracket and Elevator Foot Spring from Bottom Cover.
2. Pull out Elevator Hook Noyal rightward.  
Then remove Elevator Hook Noyal, Elevator Push Spring and Elevator Foot Noyal.

# Function Of Boards

# 5

This section provides each connector location on boards, signal and function of each board. They will be useful for your detecting the defective boards.




## 5-1 DMD Board

### 5-1.1 The Locations of Connectors

J1



J501



## 5-1.2 J501 : Color Wheel Connector

PIN#	Signal Name	Description	PIN#	Signal Name	Description
1	CWCTR	Color Wheel Motor Drive Signal	2	CWY3	Color Wheel Motor Drive Signal
3	CWY2	Color Wheel Motor Drive Signal	4	CWY1	Color Wheel Motor Drive Signal

## 5-1.3 J1 : To Main Board Connector

PIN#	Signal Name	Description	PIN#	Signal Name	Description
1	GND	Ground	2	GY6	Digital Green Signal Input
3	GY7	Digital Green Signal Input	4	GND	Ground
5	GND	Ground	6	GY4	Digital Green Signal Input
7	GY5	Digital Green Signal Input	8	GND	Ground
9	GND	Ground	10	GY2	Digital Green Signal Input
11	GY3	Digital Green Signal Input	12	GND	Ground
13	GND	Ground	14	GY0	Digital Green Signal Input
15	GY1	Digital Green Signal Input	16	GND	Ground
17	GND	Ground	18	RV6	Digital Red Signal Input
19	RV7	Digital Red Signal Input	20	GND	Ground
21	GND	Ground	22	RV4	Digital Red Signal Input
23	RV5	Digital Red Signal Input	24	GND	Ground
25	GND	Ground	26	RV2	Digital Red Signal Input
27	RV3	Digital Red Signal Input	28	GND	Ground
29	GND	Ground	30	RV0	Digital Red Signal Input


PIN#	Signal Name	Description	PIN#	Signal Name	Description
31	RV1	Ditigal Red Signal Input	32	GND	Ground
33	GND	Ground	34	BU6	Ditigal Blue Signal Input
35	BU7	Ditigal Blue Signal Input	36	GND	Ground
37	GND	Ground	38	BU4	Ditigal Blue Signal Input
39	BU5	Ditigal Blue Signal Input	40	GND	Ground
41	GND	Ground	42	BU2	Ditigal Blue Signal Input
43	BU3	Ditigal Blue Signal Input	44	GND	Ground
45	GND	Ground	46	BU0	Ditigal Blue Signal Input
47	BU1	Ditigal Blue Signal Input	48	GND	Ground
49	GND	Ground	50	OLACT	Overlay Active
51	ACTDATA	Data Enable	52	GND	Ground
53	GND	Ground	54	HSYNCZ	Horizontal Sync.
55	VSYNCZ	Vertical Sync.	56	GND	Ground
57	GND	Ground	58	SYNCVAL	Sync. Valid
59	CLKIN	Data Clock	60	GND	Ground
61	GND	Ground	62	LAMPEN	Lamp Enable
63	RESETZ	Reset Sync.	64	LAMPLITZ	Lamp Lit
65	PWRGOOD	Power Good Sync.	66	LAMPSYNC	Lamp Sync.
67	ARMTEST1	Test Point	68	PWM0	Test Point
69	ARMTEST2	Test Point	70	PWM1	Test Point

PIN#	Signal Name	Description	PIN#	Signal Name	Description
71	SDA0	Serial Data	72	GND	Ground
73	GND	Ground	74	SCL1	Serial Clock
75	SCL0	Serial Clock	76	GND	Ground
77	GND	Ground	78	SDA1	Serial Data
79	P3P3V_IN	+3.3V	80	GND	Ground
81	P3P3V_IN	+3.3V	82	TSTPNT0	Test Point
83	P3P3V_IN	+3.3V	84	TSTPNT1	Test Point
85	P3P3V_IN	+3.3V	86	TSTPNT2	Test Point
87	GND	Ground	88	TSTPNT3	Test Point
89	P2P5V_IN	+2.5V	90	P2P5V_IN	+2.5V
91	P2P5V_IN	+2.5V	92	P2P5V_IN	+2.5V
93	P2P5V_IN	+2.5V	94	P2P5V_IN	+2.5V
95	P2P5V_IN	+2.5V	96	P2P5V_IN	+2.5V
97	CWINDEX	Color Wheel Index	98	GND	Ground
99	GND	Ground	100	USBP	No Connection
101	PWM2	Test Point	102	GND	Ground
103	GND	Ground	104	USBN	No Connection
105	P5V_IN	+5V	106	GND	Ground
107	P5V_IN	+5V	108	P12V_IN	+12V
109	GND	Ground	110	P12V_IN	+12V

PIN#	Signal Name	Description	PIN#	Signal Name	Description
111	TCK	Test Point	112	GND	Ground
113	GND	Ground	114	SPARE64	Test Point
115	TD1	Test Point	116	TRSTZ	Test Point
117	TMS1	Test Point	118	TMS2	Test Point
119	TDO1	Test Point	120	TDO2	Test Point

## 5-2 Main Board

### 5-2.1 The Locations of Connectors



### 5-2.2 J10 : Speaker Connector

PIN#	Signal Name	Description	PIN#	Signal Name	Description
1	SPEAKER+	To Speaker +	2	SPEAKER -	To Speaker -

### 5-2.3 J6 : To Keypad Interface Connector

PIN#	Signal Name	Description	PIN#	Signal Name	Description
1	+3.3V	+3.3V	2	MENU	Keypad Menu Control
3	MENU-U	Keypad Up Control	4	MENU-D	Keypad Down Control
5	MENU-L	Keypad Left Control	6	MENU-R	Keypad Right Control
7	PWBOTTON	Power Button Control	8	+3.3V	+3.3V
9	GND	Ground	10	GND	Ground
11	LED1	LED1	12	LED2	LED2
13	PW_LED	Power LED	14	GND	Ground

### 5-2.4 J3 : RCA-Jack\_IP Connector

PIN#	Signal Name	Description	PIN#	Signal Name	Description
1	CVIDEO	Composite Video Input	2	GND	Ground

### 5-2.5 J4 : S-VHS Connector

PIN#	Signal Name	Description	PIN#	Signal Name	Description
1	GND	Ground	2	GND	Ground
3	SVIDEO1	Luminance Signal Input	4	SVIDEO2	Chrominance Signal Input

## 5-2.6 J5 : To DMD Board Connector

PIN#	Signal Name	Description	PIN#	Signal Name	Description
1	GND	Ground	2	GD6	Green Data
3	GD7	Green Data	4	GND	Ground
5	GND	Ground	6	GD4	Green Data
7	GD5	Green Data	8	GND	Ground
9	GND	Ground	10	GD2	Green Data
11	GD3	Green Data	12	GND	Ground
13	GND	Ground	14	GD0	Green Data
15	GD1	Green Data	16	GND	Ground
17	GND	Ground	18	RD6	Red Data
19	RD7	Red Data	20	GND	Ground
21	GND	Ground	22	RD4	Red Data
23	RD5	Red Data	24	GND	Ground
25	GND	Ground	26	RD2	Red Data
27	RD3	Red Data	28	GND	Ground
29	GND	Ground	30	RD0	Red Data
31	RD1	Red Data	32	GND	Ground
33	GND	Ground	34	BD6	Blue Data
35	BD7	Blue Data	36	GND	Ground
37	GND	Ground	38	BD4	Blue Data
39	BD5	Blue Data	40	GND	Ground



PIN#	Signal Name	Description	PIN#	Signal Name	Description
41	GND	Ground	42	BD2	Blue Data
43	BD3	Blue Data	44	GND	Ground
45	GND	Ground	46	BD0	Blue Data
47	BD1	Blue Data	48	GND	Ground
49	GND	Ground	50	OLACT	Overlay Active
51	ACTDATA	Data Enable	52	GND	Ground
53	GND	Ground	54	HSYNCZ	Horizontal Sync.
55	VSYNCZ	Vertical Sync.	56	GND	Ground
57	GND	Ground	58	SYNCVALD	Sync. Valid
59	DCLKOZ	Data Clock Output	60	GND	Ground
61	GND	Ground	62	LAMPEN	Lamp Enable
63	RESETZ	Reset	64	LAMPLITZ	Lamp Lit
65	PWRGOOD	Power Good	66	LAMPSYNC	Lamp Sync.
67	ARMTEST1	Test Point	68	PWM0	Test Point
69	ARMTEST2	Test Point	70	PWM1	Test Point
71	SDA	Serial Data	72	GND	Ground
73	GND	Ground	74	SCL1	Serial Clock
75	SCL	Serial Clock	76	GND	Ground
77	GND	Ground	78	SDA1	Serial Data
79	+3.3VIN	+3.3V	80	GND	Ground

PIN#	Signal Name	Description	PIN#	Signal Name	Description
81	+3.3VIN	+3.3	82	TSTPNT0	Test Point
83	+3.3VIN	+3.3	84	TSTPNT1	Test Point
85	+3.3VIN	+3.3	86	TSTPNT2	Test Point
87	GND	Ground	88	TSTPNT3	Test Point
89	+2.5VDMD	+2.5V	90	+2.5VDMD	+2.5V
91	+2.5VDMD	+2.5V	92	+2.5VDMD	+2.5V
93	+2.5VDMD	+2.5V	94	+2.5VDMD	+2.5V
95	+2.5VDMD	+2.5V	96	+2.5VDMD	+2.5V
97	CWINDEX	Color Wheel Index	98	GND	Ground
99	GND	Ground	100	N.C.	No Connection
101	PWM2	Test Point	102	GND	Ground
103	GND	Ground	104	N.C.	No Connection
105	+5V	+5V	106	GND	Ground
107	+5V	+5V	108	+12V	+12V
109	GND	Ground	110	+12V	+12V
111	TCK	Test Point	112	GND	Ground
113	GND	Ground	114	SPARE64	Test Point
115	TD1	Test Point	116	TRSTZ	Test Point
117	TMS1	Test Point	118	TMS2	Test Point
119	TDO1	Test Point	120	TDO2	Test Point

### 5-2.7 J7 : To Thermal Board

PIN#	Signal Name	Description	PIN#	Signal Name	Description
1	GND	Ground	2	GND	Ground
3	+5V	+5V	4	+5V	+5V
5	+5V	+5V	6	+5V	+5V
7	GND	Ground	8	+5V	+5V
9	GND	Ground	10	GND	Ground
11	GND	Ground	12	GND	Ground
13	+12V	+12V	14	+12V	+12V
15	GND	Ground	16	GND	Ground
17	+3.3VIN	+3.3V	18	+3.3VIN	+3.3V
19	+3.3VIN	+3.3V	20	+3.3VIN	+3.3V
21	GND	Ground	22	GND	Ground
23	+5VSBY	+5V	24	+5VSBY	+5V
25	GND	Ground	26	PW_LED	Power LED
27	PWBOTTOM	Standby Sync.	28	IR_ONOFF	IR_ONOFF
29	CWINDEX	Color Wheel Index	30	LAMPEN	Lamp Enable
31	LAMPLITZ	Lamp Lit	32	SHUTDW#	Shut Down
33	PWRGOOD	Power Good	34	ERR_OUT	Error Sync. Output
35	TSDA	Serial Data	36	IR_R	IR_Data
37	TSCL	Serial Clock	38	HPDPCNT	+12V
39	LED1	LED1	40	LED2	LED2

## 5-2.8 J1 : VESA M1-Display Interface Connector


PIN#	Signal Name	Description	PIN#	Signal Name	Description
1	RX2+	Transmit Data	2	RX2-	Transmit Data
3	RX2 Shield	Ground	4	RXC Shield	Ground
5	HSYNC	Analog Horizontal Sync. Input	6	VSNC	Analog Vertical Sync. Input
7	N.C.	No Connection	8	+5VHPD	+5V
9	N.C.	No Connection	10	N.C.	No Connection
11	RX1+	Transmit Data	12	RX1-	Transmit Data
13	RX1 Shield	Ground	14	RXC+	Transmit Data
15	RXC-	Transmit Data	16	USB_D+	Remote Mouse USB+
17	USB_D-	Remote Mouse USB-	18	N.C.	No Connection
19	EDID_W	EDID Write USE	20	DWLOAD	Firmware Download Use
21	RX0+	Transmit Data	22	RX0-	Transmit Data
23	RX0 Shield	Ground	24	USB +5V Input	+5V
25	GND	Ground	26	DDCDAT	DDC Data
27	DDCCLK	DDC Clock	28	DDC+5V	+5V
29	M1_RXD	Firmware Download Use	30	M1_TXD	Firmware Download Use
C1	VGAIN_R	Analog Red Sync. Input	C2	VGAIN_G	Analog Green Sync. Input
C3	VGAIN_B	Analog Blue Sync. Input	C4	VGAIN_B	Analog Blue Sync. Input
C5	Video Return	Ground			

### 5-2.9 J9 : Audio In Connector

PIN#	Signal Name	Description	PIN#	Signal Name	Description
1	GND	Ground	2	AIN_R	Audio Right Channel Input
3	AIN_L	Audio Right Channel Input	4	N.C.	No Connection
5	N.C.	No Connection			

## 5-3 Keypad Board

### 5-3.1 The Locations of Connectors




### 5-3.2 J1 : Keypad Connector

PIN#	Signal Name	Description	PIN#	Signal Name	Description
1	+5V	+5V	2	MENU	Keypad Menu Control
3	MENU-U	Keypad Up Control	4	MENU-D	Keypad Down Control
5	MENU-L	Keypad Left Control	6	MENU-R	Keypad Right Control
7	PWBOTTON	Power Button Control	8	+5VSB	+5V
9	GND	Ground	10	GND	Ground
11	LED1	LED1	12	LED2	LED2
13	PW_LED	PW_LED	14	GND	Ground

## 5-4 Thermal Board

### 5-4.1 The Locations of Connectors



#### 5-4.2 J5 : Fan3 Connector

PIN#	Signal Name	Description	PIN#	Signal Name	Description
1	FAN_POWER3	Fan3 Power	2	FAN_LOCK	FAN Lock Sync.
3	GND	Ground			

#### 5-4.3 J3 : Fan2 Connector

PIN#	Signal Name	Description	PIN#	Signal Name	Description
1	FAN_POWER2	Fan2 Power	2	FAN_LOCK	FAN Lock Sync.
3	GND	Ground			

#### 5-4.4 J8 : Thermal Switch Connector

PIN#	Signal Name	Description	PIN#	Signal Name	Description
1	THERMAL_ERROR#	Thermal Error Sync.	2	GND	Ground

#### 5-4.5 J6 : Photo Sensor Connector

PIN#	Signal Name	Description	PIN#	Signal Name	Description
1	GND	Ground	2	PHOTO_IN	Photo Sensor Input Signal
3	+3.3V	+3.3V			



#### 5-4.6 J2 : Fan4 Connector

PIN#	Signal Name	Description	PIN#	Signal Name	Description
1	FAN_POWER4	Fan1 Power	2	FAN_LOCK	Fan Lock Sync.
3	GND	Ground			

#### 5-4.7 J4 : Fan1 Connector

PIN#	Signal Name	Description	PIN#	Signal Name	Description
1	FAN_POWER1	Fan1 Power	2	FAN_LOCK	Fan Lock Sync.
3	GND	Ground			

#### 5-4.8 J10 : IR Receiver Connector

PIN#	Signal Name	Description	PIN#	Signal Name	Description
1	IR_R	IR Receiver	2	GND	Ground
3	+5VSBY	+5V Standby Power			

#### 5-4.8 J11 : To Lamp Ballast Connector

PIN#	Signal Name	Description	PIN#	Signal Name	Description
1	LAMPEN_OUT	Lamp Enable Sync.	2	GND	Ground
3	LAMPLIT_IN	Lamp Lit Feedback Sync.			

#### 5-4.9 J7 : To DC-DC Connector

PIN#	Signal Name	Description	PIN#	Signal Name	Description
1	LAMPEN_OUT	Lamp Enable	2	+3.3VSBY	+3.3V
3	+5VSBY	+5V	4	GND	Ground
5	GND	Ground	6	+13.1VSBY	+13.1V
7	+13.1VSBY	+13.1V	8	N.C.	No Connection
9	GND	Ground	10	GND	Ground
11	GND	Ground	12	+5VSBY	+5V
13	+13.3VSBY	+3.3V	14	LAMPLIT_IN	Lamp Lit


#### 5-4.10 JP2 : To Main Board Connector

PIN#	Signal Name	Description	PIN#	Signal Name	Description
1	GND	Ground	2	GND	Ground
3	+5V	+5V	4	+5V	+5V
5	+5V	+5V	6	+5V	+5V
7	GND	Ground	8	+5V	+5V
9	GND	Ground	10	GND	Ground
11	GND	Ground	12	GND	Ground
13	+12V	+12V	14	+12V	+12V
15	GND	Ground	16	GND	Ground
17	+3.3V	+3.3V	18	+3.3V	+3.3V
19	+3.3V	+3.3V	20	+3.3V	+3.3V

PIN#	Signal Name	Description	PIN#	Signal Name	Description
21	GND	Ground	22	GND	Ground
23	+5VSBY	+5V	24	+5VSBY	+5V
25	GND	Ground	26	PW_LED	Power LED
27	PWBOTTON	Standby Sync.	28	IR_ONOFF	IR_ONOFF
29	CWINDEX	Color Wheel Index	30	LAMPEN	Lamp Enable
31	LAMPLIT	Lamp Lit	32	SHUT_DOWN#	Shut Down Sync.
33	PWRGOOD	Power Good	34	ERR_OUT	Thermal Error Sync.
35	TSDA	Serial Data	36	IR_R	IR_Data
37	TSCL	Serial Clock	38	+13.1VSBY	+13.1V
39	LED1	LED1	40	LED2	LED2

## 5-5 DC-DC Board

### 5-5.1 The Locations of Connectors



### 5-5.2 J2 : Interlock Connector

PIN#	Signal Name	Description	PIN#	Signal Name	Description
1	LAMP INTERLOCK	Lamp Door Interlock	2	LAMP INTERLOCK	Lamp Door Interlock

### 5-5.3 J1 : To Ballast Connector


PIN#	Signal Name	Description	PIN#	Signal Name	Description
1	SYSTEM POWER	+400V	2	N.C.	No Connection
3	GND	Ground	4	SYSTEM POWER	+12V

#### 5-5.4 J4 : To Thermal Board Connector

PIN#	Signal Name	Description	PIN#	Signal Name	Description
1	LAMPEN_OUT	Lamp Enable Signal Output	2	+3.3VSBY	+3.3V Standby Power
3	+5VSBY	+5V Standby Power	4	GND	Ground
5	GND	Ground	6	+13.1 VSBY	+13.1V Standby Power
7	+13.1VSBY	+13.1V Standby Power	8	N.C.	No Connection
9	GND	Ground	10	GND	Ground
11	GND	Ground	12	+5VSBY	+5V Standby Power
13	+3.3VSBY	+3.3V Standby Power	14	LAMPLIT_IN	Lamp Lit Signal Input

## 5-6 Ballast

### 5-6.1 The Locations of Connectors



### 5-6.2 CN3 : Control Board Connector

PIN#	Signal Name	Description	PIN#	Signal Name	Description
1	LAMPEN_OUT	Start Control Input	2	GND	Ground
3	LAMPLIT	Fla Output			

### 5-6.2 CN1 : Power Supply Connector

PIN#	Signal Name	Description	PIN#	Signal Name	Description
1	+400V	+400V	2	N.C.	No Connection
3	GND	Ground	4	VCC	+12V

# Specifications

# 6

This chapter provides DMD, Lamp, Lamp Driver and DC-DC specifications. All specifications are for your reference.

## 6-1 Lamp Specifications

### ■ Operating and Measurement Conditions

Ballast type	Test conditions stable at 150W with OSRAM PT VIP 150 AC/100-240 HI ballast
Rated lamp wattage	150W
Burner position	0° to +20° (0° optical axis horizontal)
Burning position	Horizontal

### ■ Temperature

Lamp burner Mo foil, back	< 350°C
Lamp burner Mo wire	< 400°C
Lamp burner Mo foil, front	< 350°C
Burner temperature	900oC~1000oC

*Validation of max. permissible temperatures by reference thermocouple measurement based on a reference lamp housing.*

### ■ Typical Burner Characteristics (Initial)

UV-output	UVA (315-400 nm) 9W typical UVB (280-315 nm) < 0,13 W UVC (248-280 nm) < 0,013 W
UV-output through dichroic reflector	(248-400 nm) 2.5W typical
Total visible flux	(400-780 nm) 38W typical
IR	(780-2500 nm) 38W typical



## ■ Average Lamp Life and Lumen Maintenance

Switching cycle	3.5 hrs on 0.5 hrs off
Lamp life time	1000 hrs typical
Lamp life	Lamp output > 50% of initial lumen output

## ■ Rise Time

Rise time to 80% of the stabilized luminous output is < 90 sec without forced convection.  
Extensive cooling of the bulb during lamp run-up phase has to be avoided.

## ■ Light output

Ballast type	Test conditions on electronic power supply OSRAM PT VIP 150 AC/100-240 HI stable
Stabilization time	5 min, without forced cooling
Luminous flux through aperture	Typ. : 5400 lm @ 5.0 x 3.8 mm <sup>2</sup> rect. aperture
Rectangular aperture	Min. : 5000 lm @ 5.0 x 3.8 mm <sup>2</sup> rect. aperture
Color coordinates	Typ. x : 0.280 +/- 0.020 Typ. y : 0.290 +/- 0.020

## ■ Hot Restrike

If the unit has been off for more than 60 sec. the lamp must restrike.  
(Ignition voltage 20 kV +/- 3 kV)  
No forced cooling is required following lamp switch-off.

## ■ Instructions for use

- For lamp replacement : switch off power, disconnect power cord, allow lamp to reach room temperature.
- This VIP lamp operates at high pressure and at high temperature and may unexpectedly shatter.
- This VIP lamp generates ultraviolet radiation which may cause skin and eye irritation with prolonged exposure.
- This VIP lamp must be operated only in suitably designed, enclosed fixtures which prevent direct observation of the arc and will prevent lamp fragments from exiting, in the unlikely event of a lamp shattering.
- The burning position is 0° to +/- 15° (0° optical axis horizontal).
- Do not touch the lamp with bare hands.
- If necessary, lamp can be cleaned with lint free towel before operation.
- The lamp must be operated with the OSRAM lamp driver PT VIP 150 AC/100-240 H1.
- Protect lamp environment against high ignition pulses.
- Avoid direct contact of objects to reflector cover glass.
- Faster on-off-cycles than specified will reduce lamp life.
- For most stable, i.e. flickerfree, operation, it is recommended to operate lamp at drive frequencies (via SCI signal) of 300Hz or greater.
- Operate lamp only in accordance to UL 1950 regulations.
- This lamp must not be operated with a broken, cracked or loose reflector or cover glass.
- Do not operate the lamp in proximity to paper, cloth, or other combustible material nor cover it with such materials. Otherwise it could cause a fire.
- Do not operate the lamp in an atmosphere containing an inflammable substance, such as thinner. Otherwise it could cause a fire or explosion.
- Thoroughly ventible the area of the room when operating teh lamp in an oxygen atmosphere (in the air). If ozone is inhaled, it could cause headaches, nausea, dizziness, etc.
- Leave the area immediately if the lamp shatters while being operated and ventilate the area for at least 30 minutes in order to avoid the inhalation of mercury fumes. Otherwise, it could be harmful to user's health.

**Disposal** For disposal of spent lamps, always consult federal, state, local and provincial hazardous waste disposal rules and regulations to ensure proper disposal.

**Caution** This lamp emits ultra violet (UV) radiation and operates at high pressure. This lamp may only be used in enclosed fixtures that comply with UL1572. Due to the high within the lamp, P-VIP® lamps may only be operated within enclosed, purpose-built housings.

## 6-2 DMD Specifications

Table 1. Physical, Optical and Thermal Parameters

<i>Parameter</i>	<i>Min</i>	<i>Nom</i>	<i>Max</i>	<i>Unit</i>
<i>Physical</i>				
Number of columns		1024		
Number of rows		768		
Mirror pitch (width)		13.68		μm
Total width (active mirror array) [1024 pixels]	---	14.008	---	mm
Total height (active mirror array) [768 pixels]	---	10.506	---	mm
<i>Optical</i>				
Mirror tilt (half angle) (Note 1)	11	12	13	Degrees
Axis of rotation - upper right to lower left	44	45	46	Degrees
Flatness gradient over total mirror array			0.1	%
Active area fill factor (by design)		85.2		%
Mirror metal specular reflectivity (420-700nm)		89.4		%
Window material designation (Type A)		Coming 7056		
Window refractive index @ 545nm (Type A)		1.487		
Window transmittance - including AR coating, measured @ 420-680 nanometers (Note 3)	97			%
Window flatness (@ 550 nanometers) spherical power/irregularity (astigmatism, etc.)			4/12	fringes
Window aperture photopic reflectivity			23	%
<i>Thermal</i>				
Thermal impedance, active area to case (Note 4)			0.6	°C/W

**Note 1 : Tilt Angle Tolerances**

Limits on variability of mirror tilt half angle are critical in the design of the accompanying optical system. Variations in tilt angle within a device may result in apparent non-uniformities, such as line pairing and image mottling, across the projected image. Variations in the average tilt angle between devices may result in colorimetry and system contrast variations. The specified limits represent the tolerances of the tilt angles within a device.

**Note 2 : Active Area Reflectivity**

The DMD specular reflectivity is defined as the ratio of the light incident upon the mirror array to the light specularly reflected from it. The measurement is made with all mirrors in the full on state without electronic duty cycle effects (i.e. measure using 100% duty cycle). The specified specular reflectivity applies to any arbitrary point on the DMD active area.

**Note 3 : Window Transmittance**

Angle of incidence 0° - 45° at 42-680nm. Double pass system. Two AR coating surfaces at 0.5% reflectivity per AR coating.

**Note 4 : Thermal Performance**

The DMD is designed to conduct absorbed and dissipated heat to the back of the package where it can be removed by an appropriate heat sink. The heat sink and cooling system must be capable of maintaining the package within the specified operational temperatures. The total heat load on the DMD is largely driven by the incident light absorbed by the active area although other contributions include light energy absorbed by the window aperture and electrical power dissipation of the array. Optical systems should be designed to minimize the light energy falling outside the window clear aperture since any additional thermal load in this area can significantly degrade the reliability of the device. For more information on thermal characteristics and applications of the 0.7XGA DMD, refer to Texas Instruments DMD Thermal Guide for 0.7XGA Type A.

Table 2. Absolute Max. Ratings

<i>Parameter</i>	<i>Min</i>	<i>Max</i>	<i>Unit</i>
Logic supply voltage, VCC	-0.5	4.5	VDC
Mirror electrode voltage, VCC2	-0.5	8	VDC
Readback reference voltage, EVCC	-0.5	4.5	VDC
Input Voltage, MBRST	-2.8	2.8	V
Input Voltage, other inputs	-0.5	4.5	VDC
Short circuit output current		+/-25	mA
Operating temperature - for array and points 1,2 & 3	0	65	°C
Differential temperature - any two of the reference points 1, 2 & 3		15	°C
Storage temperature	-40	80	°C
Operating relative humidity (none-condensing)	0	95	%
Storage relative humidity (none-condensing)	0	95	%
Mechanical Stud Attach Load		35	pounds-force

## 6-3 DC-DC Specifications

### ■ Dimensions and Weight

DC-DC Converter Size	70 x 42 x 27mm
----------------------	----------------

DC-DC Converter Weight	46g
------------------------	-----

### ■ DC-DC Converter Data

	Normal	Max.
Input Wattage	32W	50W
Power Dissipation	7W	12W
Output Voltage1	3.3V	
Output Current1	1.5A	2.0A
Output Voltage2	5V	
Output Current2	1.5A	2.5A
Output Voltage3	13V	
Output Current3	1.0A	1.5A

## 6-4 Lamp Driver Specifications

### ■ Dimensions and Weight

Lamp Driver Size	177 x 50 x 31mm
Lamp Driver Weight	250g

### ■ Lamp Driver Data

Input Voltage, normal	100V-240VAC, 50/60Hz
Input Current, normal	2.1A-0.9A
Input Wattage, normal	210W
Power Dissipation	20W normal, 30W max.
Output Voltage (Lamp)	85V AC rectangular
Output Current (Lamp)	1.8A max. 2.4A
Output Wattage (Lamp)	156W (at R=46.3ohm at 85V)
Ignition Pulse	Typ. 8kVpeak symm. max. 10kV peak symm. Typ. 1.5s max. 4s
Hot Restrike Delay	60s max.
Enable-Disable-Enable Cycle	15s min.
Switch off Lamp Voltage	135V 130-140V
Cooling Method	Forced air cooling at 1.5m/s minimum
Thermal Protection	T1 switch point 100°C +/-5°C
Electrical Protection	Short cut + output /- output for max. 10s no protection for short to GND

### ■ Environmental Requirements for Lamp and Lamp Driver

<b>Ambient Temperature</b>	Operating : 10°C to 40°C Non-operating : -20°C to 70°C
<b>Humidity</b>	Operating : 5% to 95% relative, non-condensing Non-operating : 5% to 95% relative, non-condensing
<b>Altitude</b>	Operating : max. 10,000ft (3,000m) @ 40°C Non-operating : max. 40,000ft @ 70°C
<b>Vibration</b>	Operating : random, standalone 0.015g <sup>2</sup> /Hz 5Hz to 1000Hz, all primary axis, 30 minutes per orientation Non-operating : sine, standalone Q≤5 1G control, 5Hz to 500Hz, all three primary axis, 5 minutes sweep rate
<b>Shock)</b>	Operating : standalone 50g 11 ms half sine pulse, all primary axis, three shocks per orientation
<b>Note : Lamp mounting must ensure the a.m. vibration and shock conditions.</b>	



# Troubleshooting


# 7


This chapter provides technicians and people who have an electronic background a primary description about maintaining the product. Moreover, you can get the appropriate operation to solve some complicated problems of component repairing and professional problems.

## 7-1 Equipment Needed


- EP737 Projector
- VESA M1 to VGA Cable
- PC (Personal Computer)
- Audio Input, Video Input
- Screw Drivers

## 7-2 Main Procedure







### 7-2.1 A. Power Troubleshooting



## 7-2.2 B. Performance Troubleshooting






### **Color Adjust Procedure :**

\* Notice : PC shall run R.G.B. gray scale pattern.


1. Power on. Press “Up”, “Up”, “Left” button when the “No Signal” show on the screen.
2. Choose “Display Source”
3. Choose Color Wheel Index.
4. Press “Left” or “Right” button to adjust.

► Note 1 : It may need to be used when you replace Main Board or Optical Engine alone.

### 7-2.3 C. Function Troubleshooting




#### 7-2.4 D. Audio Troubleshooting





## 7-2.5 E. Remote Control Troubleshooting



# Function Test & Alignment Procedure

# 8

This chapter provides equipment, conditions, patterns, and procedure needed for Function Test and Alignment. It also includes compatible modes. All information is for your reference.

## 8-1 Product

- EP737 Projector

## 8-2 Test Equipment

- IBM PC with XGA resolution (Color Video Signal & Pattern Generator)
- VCR with Multi-system(NTSC/PAL/SECAM)
- Chroma meter Minolta CL-100/T-10
- Hi-Pot

## 8-3 Test Condition

- Circumstance Brightness : Dark room less than 10 lux
- Inspection Distance : 2.0m
- Screen Size : 60 inches diagonal (wide)
- Before function test and alignment, each EP737 should be run-in and warmed-up for at least 5 minutes with following conditions.
  - 1.) In room temperature
  - 2.) With cycled display colors (R,G,B,White)
  - 3.) With cycled display modes
 

640 x 350 (H=31.5 KHz, V=70 Hz)	640 x 400 (H=31.5 KHz, V=70 Hz)
640 x 480 (H=37.5 KHz, V=75 Hz)	720 x 400 (H=31.5 KHz, V=70 Hz)
800 x 600 (H=53.7 KHz, V=85 Hz)	800 x 600 (H=37.9 KHz, V=60 Hz)
1024 x 768 (H=48.4 KHz, V=60 Hz)	1024 x 768 (H=68.7 KHz, V=85 Hz)
- Test Display Mode & Pattern (Refer to 8-4.1 & 8-4.2)
- Function Test and Alignment Procedure

## 8-4 Test Display Modes and Patterns

### 8-4.1 Compatible Modes

Analog :

Resolution	V-Sync(Hz)	H-Sync(KHz)	Compatibility
640 x 350	70	31.5	VGA
640 x 350	85	37.9	VGA
640 x 400	70	31.5	VGA
640 x 400	85	37.9	VGA
640 x 480	60	31.5	VGA
640 x 480	72	37.9	VGA
640 x 480	75	37.5	VGA
640 x 480	85	43.3	VGA
720 x 400	70	31.5	VGA
720 x 400	85	37.9	VGA
800 x 600	56	35.2	SVGA
800 x 600	60	37.9	SVGA
800 x 600	72	48.1	SVGA
800 x 600	75	46.9	SVGA
800 x 600	85	53.7	SVGA
1024 x 768	43.4	35.5	XGA
1024 x 768	60	48.4	XGA
1024 x 768	70	56.5	XGA
1024 x 768	75	60.0	XGA
1024 x 768	85	68.7	XGA
1280 x 1024	60	63.98	SXGA
1280 x 1024	75	79.98	SXGA

Analog :

Resolution	V-Sync(Hz)	H-Sync(KHz)	Compatibility
640 x 480	66.66	34.98	MAC LC 13"
640 x 480	66.68	35	MAC II 13"
832 x 624	74.55	49.725	MAC 16"
1024 x 768	75	60.24	MAC 19"
1152 x 870	75.06	68.68	MAC
640 x 480	60	31.35	MAC G4
640 x 480	120	68.03	MAC G4
1024 x 768	120	97.09	MAC G4
640 x 480	117	60	i MAC DV
800 x 600	95	60	i MAC DV
1024 x 768	75	60	i MAC DV
1152 x 870	75	68.49	i MAC DV
1280 x 960	75	75	i MAC DV
1280 x 1024	85	90.9	i MAC DV

Digital :

Resolution	V-Sync(Hz)	H-Sync(KHz)	Compatibility
640 × 350	70	31.5	VGA
640 × 350	85	37.9	VGA
640 × 400	70	31.5	VGA
640 × 400	85	37.9	VGA
640 × 480	60	31.5	VGA
640 × 480	72	37.9	VGA
640 × 480	75	37.5	VGA
640 × 480	85	43.3	VGA
720 × 400	70	31.5	VGA
720 × 400	85	37.9	VGA
800 × 600	56	35.2	SVGA
800 × 600	60	37.9	SVGA
800 × 600	72	48.1	SVGA
800 × 600	75	46.9	SVGA
800 × 600	85	53.7	SVGA
1024 × 768	60	48.4	XGA
1024 × 768	70	56.5	XGA
1024 × 768	75	60.0	XGA

### 8-4.2 Function Test Display Pattern

Item	Test Content	Pattern	Specification	Remark
1	Frequency & Tracking	Fine Line Moire	Eliminate visual wavy noise.	Figure 1
2	Contrast/Brightness	Gray Scale	Gray levels should be distinguishable.	Figure 2
3	R, G, B and White Color Performance	R, G, B and White Color	Each R, G, B color should be normal.	Figure 3~6
4	Screen Uniformity & Flicker	Full White	Should be compliant with the like new spec.	Figure 6
5	Dead/Blemish Pixel	R, G, B, White, Dark, Blue 180, Gray 30	The numbers of dead/blemish pixels should be compliant with the like new spec.	Figure 3~9
6	Boundary	Boundary Frame	Horz. and Vert. position of video should be adjustable to be within the screen frame.	Figure 7



Fine Line Morie Pattern (Figure 1)



Contrast &amp; Brightness (Figure 2)



R. Color Pattern (Figure 3)




G. Color Pattern (Figure 4)







B. Color Pattern (Figure 5)



Full White Pattern (Figure 6)




Dark Pattern (Figure 7)



Gary 30 Pattern (Figure 8)



Blue 180 Pattern (Figure 9)



Boundary Frame (Figure 10)

## 8-5 Inspection Procedure

### **RESET:**

Please press “Menu” button on the projector panel to enter “Image-II” Function then choose “Reset Function”, press “Left Button” to choose “YES” and to see if it works. This action will allow you to erase all end-user’s settings and restore the original factory setting.

### **Hi-Pot and Grounding Test :**

- Hi-Pot Specification : 1.5kVAC, 10mA, 2 seconds.
- Grounding Specification : 12VDC, 25A, 0.1 ohm.

### **Clock and Clock Phase :**

Test Signal : 1024 x 768 @ 75Hz

Test Pattern : Line Moire Pattern

- Check and see if image sharpness and focus is well performed.
- If not, readjust by following steps.
  - Enter “Image-II” menu and select “Frequency” Function to adjust the total pixel number of pixel clock in one line period.
  - Then select “Tracking” Function and use right or left arrow key to adjust the value to minimize video flicker.

### **R, G, B and White Colors Contrast :**

Test Signal : 1024 x 768 @ 75Hz

Test Pattern : 64 or 16 R, G, B and White colors Intensities Pattern

- Please check and see if each colors is normal and distinguishable.
- If not, please return the unit to repair area.

### **Screen Uniformity and Flicker :**

Test Signal : 1024 x 768 @ 75Hz

Test Pattern : Full White Pattern

- Please check and see if it's in normal condition.
- If not, please return the unit to repair area.

### **Dead Pixel/Blemish Pixel :**

Test Signal : 1024 x 768 @ 75Hz

Test Pattern : Gray 30, Blue 180, White, Dark, Red, Green and Blue Pattern

- Please check and see if there are dead pixels on DMD chip.
- The total numbers and distance of dead pixels should be complaint with like new specification.

### **Check for Secondary Display Modes**

- Test signal :
- 1.) 640 x 350 @ 70.09 / 85.08Hz
  - 2.) 640 x 480 @ 72.81 / 75.00 / 85.01Hz
  - 3.) 720 x 400 @ 70.08 / 85.04Hz
  - 4.) 800 x 600 @ 56.25 / 60.32 / 72.19 / 75.00 / 85.06Hz
  - 5.) 832 x 624 @ 74.55Hz
  - 6.) 1024 x 768 @ 43.48 / 60.00 / 70.00 / 75.03 / 85.00Hz

Normally when the primary mode 1024 x 768 @ 85Hz is well adjusted and complaint with the like new specification, then the secondary display modes will be great possibility to be complaint with the specification. But we still have to check with general test pattern to make sure every secondary modes is complaint with like new specification.

### **Factory Reset :**

After final QC step, we have to erase all saved change again and restore the factory defaults. Please select and enter "Factory Reset" Function to see if it is workable. This action will allow you erase all end-user's settings and restore the original factory setting.

# Firmware Upgrading Procedure

# 9

This chapter provides the related information about the necessary equipment, hardware setup and software upgrade procedures for Firmware Upgarde. The data is for your reference.

## 9-1 Equipment Needed

### \* Software :

- Bootcode.axe
- Bootcode.hex
- Configdata.hex
- Gui.hex
- RomCode.axe
- Flasher.hex
- pwSDK.inf
- ChkSum.txt
- Flasher.hex
- DISPSUM.exe
- FlashUpgrader MFC Application

### \* Hardware :

- Fixture
  1. Cable RS-232(Blue) To MINI DIN 3PIN 1800mm EP737. ([P/N : 42.86301.001, Rev.A](#))



- PC
- EP737 Projector


## 9-2 Setup Procedure

1. Connect RS232 to mini din 3Pin cable to COM1 of PC and EP737.




## 9-3 Upgrading Procedure

1. Execute "FlashUpgrader MFC Application".




- Click "Choose" button.







3. Search <pwSDK.inf> file from EP737 F/W folder, then click “Open” button.




4. Select "Serial" Port.



5. Select "COM1" Port.




6. Select Baud Rate to be “115200”, then click “Flash” button.




7. Plug in the Power Cord to EP737, then press and hold on “Standby” key on EP737 keypad.


*Note : The Firmware upgrade program will be stop if you havn't hold the standby button.*




8. Downloading <Flasher.hex> and <Gui.hex> files.



9. Keep on downloading <RomCode.hex> file.



10. After <Configdata.hex> file is downloaded, await starting up EP737 (about 2-3 seconds), then finish the upgrading procedure





# DDC Key-in Procedure 10

This chapter provides the related information about the necessary equipment, DDC key-in procedure. The data is all for your reference.

## 10-1 Equipment Needed

- \* Fixture
- \* PC set
- \* Power Cord
- \* Power Adapter
- \* DVI TO M1 Cable
- \* VGA TO M1 Cable (P/N : 42.85804.001)
- \* DFP TO DVI Adapter
- \* RS232 cable (P/N : 42.83618.001)
- \* EP737 Projector
- \* EDID Driver : depends on the model



1). DVI TO M1 Cable (For Digital)  
2). DFP TO DVI Adapter



VGA TO M1 Cable (For Analog)



Power Adapter




Power Cable



RS232 Cable

## 10-2 Setup Procedure

1. Plug in the power of the fixture
2. JP1 and JP5 on the fixture are close, and JP2 is open. (Figure 1)
3. Turn on the fixture.
4. Confirm "A" is short circuit.




(Figure 1 : Fixture)

## 10-3 DDC Key-in Procedure

### 10-3.1 Digital :

1. Connect P1 of the fixture with COM1 port of PC by RS232 cable.
2. Connect P3 of the fixture with M1-D/A Input Port of EP737 by DVI TO M1 cable.
3. Connect Power of the fixture with power source by Power Adapter.




(Figure 1 : Finish Setup)


1. Turn on EP737 and run EDID program in the computer.



2. The following picture will show on the screen.




- Key S/N into the blank space beside “Bar Code”, then press “Enter” key on keyboard to begin programming.



4. After finishing the above actions, "DFP Success" will appear on the screen.
5. Power on EP737, then input digital signal. If there is no display, it means EDID isn't keyed in successfully. Please repeat the step 1~5 again.

(Note : Can't run two EDID programs at the same time.)




Successful signal



### 10-3.2 Analog :


1. Connect P1 of the fixture with COM1 port of PC by RS232 cable.
2. Connect P3 of the fixture with M1-D/A Input Port of EP737 by DVI TO M1 cable.
3. Connect Power of the fixture with power source by Power Adapter.
4. Connect AC Power Input Port of EP737 with power source by Power Cord.




1. Turn on EP737 and run EDID program in the computer.




2. The following picture will show on the screen.




3. Key S/N into the blank space beside “Bar Code”, then press “Enter” key on keyboard to begin programming.



4. Execute EDID programming, wait a moment.



5. After finishing the above actions, “VGA Success” will appear on the screen.  
 (Note : Can’t run two EDID programs at the same time.)



# Appendix



## 11-1 Serial Number System Definition

### 11-1.1 Serial Number Format for Projector

A   BBB   Y   WW   C   D   BEMO   EEEE  
 ①   ②   ③   ④   ⑤   ⑥   ⑦   ⑧

- ① : A = Optoma, B~Z = OEM
- ② : Product code (ex: 863 = EP737)
- ③ : Y = Last number of the year (ex: 2002 - 2)
- ④ : Week of year
- ⑤ : Panel vendor code
- ⑥ : Electrical classification (1=110V, 2=220V, 0=universal)
- ⑦ : B = BIOS version, E = PCB board version,  
M = Mechanical version, O = Optical version
- ⑧ : Serial code (from 0001~)

#### EX : A863235T0AAAA1001

This label “A863235T0AAAA1001” represents the whole serial number for EP737, including Ver. 1st of BIOS and Ver. 1 of PCB Board. Both mechanical and optical version are 1st. In addition, panel vendor is T1. It's produced on 35-week of 2002 for universal area and its serial code is 1001.



## \* Reader's Response \*

### **Dear readers:**

*Thank you for your backing our service manual up. In order to refine our content of the service manual and satisfy your requirement. We expect you can offer us some precious opinions for reference.*

### **Assessment :**

A. What do you think about the content after reading EP737 Service Manual?

Unit	Excellent	Good	Fair	Bad
1. Introduction				
2. Fundamental Principle				
3. Mechanical Construction				
4. Procedure of Disassembly				
5. Function of Boards				
6. Specifications				
7. Troubleshooting				
8. Function Test & Alignment Procedure				
9. Firmware Upgrading Procedure				
10. DDC Key-In Procedure				
11. Appendix				

B. Are you satisfied with the EP737 service manual?

Item	Excellent	Good	Fair	Bad
1. Service Manual Content				
2. Service Manual Layout				
3. Format and Listing				
4. CD Label and Autorun Design				

C. Do you have any other opinion or suggestion about this service manual?

---



---



---



---



---

### **Reader's basic data:**

Name:		Title:	
Company:			
Add:			
Tel:		Fax:	
E-mail:			

*After your finishing this form, please send it back to Coretronic Customer Service Dept. by fax: 886-3-578-8357 or E-mail to [service@coretronic.com](mailto:service@coretronic.com) Thanks :)*